safe \cdot timeless \cdot beautiful







markilux 5010

The cassette awning - slim, strong and simply stylish





The cassette awning - slim, strong and simply stylish

design features

- · The slim cassette awning with the elegant lines from the design studio.
- The cover profile is in the same colour as the cassette; This provides for an homogeneous appearance even when the awning is extended.
- · Attractive, rounded end caps complete the overall appearance of this slim cassette awning.
- · for long-lasting attractiveness the awning has been powder coated.
- · Attractive brackets; Design down to the last detail.


technical highlights


- Because of its superior design the markilux 5010 belongs to the sturdiest and most stable of awnings on the market in spite of its slender shape.
- · Front profile with integrated gutter and hidden water drainage spouts.
- · When closed the folding arms are protected from the weather by the cassette.
- The extremely sturdy awning construction makes it possible to shade even very large areas safely.
- · The 85 mm roller tube ensures the highest rigidity and the best possible cover winding characteristics even at the largest widths.

- optional accessories · In the case of manual operation ease of use is ensured with the springassisted gearbox.
 - · Hard-wired motor drive (optionally with automatic controls) for simple, relaxed operation.
 - · Radio-controlled motor with handheld transmitter for ease of operation and ergonomically crafted for ease of use.
 - The shadeplus creates an additional room on the patio. Protection from sun, wind and inquisitive glances in one.
 - · Awning available in non-standard RAL colours
- \cdot Awning covers made from acrylic fabric or sunsilk snc with self-cleaning effect \cdot The panel joints of the awning cover are ultrasonically bonded to give a better appearance without bothersome stitching · Manual operation includes a markilux stainless steel winding handle - quality to get to grips with · Folding arms with perfected power transference by means of double, rounded steel-link chains and direct coupling of the springs. The highest safety standards even at large extensions · Folding arms with drop-forged joint components made of aluminium. The pivot bolts sit in Teflon-coated bronze bushes for high stability and longevity. The greater upper to lower arm length ratio ensures high lateral stability in the awning \cdot The use of cam bolts makes finetuning of the folding arms a simple procedure. Simply pitch adjustment via the bracket without necessitating readjustment of the front profile \cdot Awnings more than 700 cm wide can be supplied as coupled units. \cdot An easily installed sun and wind sensor provides intelligent control and essential protection · An optional wall sealing profile covers the gap between wall and awning · Available with a valance

www.samsonawnings.co.uk (0800) 328 6250


folding-arm cassette awning markilux 5010





ww.samsonawnings.co.uk (0800) 328 6250

safe \cdot timeless \cdot beautiful




markilux 5010

The cassette awning - slim, strong and simply stylish



markilux 5010 Lounge



markilux 5010













dimensions and configuration options

				0\	verall bl	ind wid	th				minimum w	idth motor 10)	minimum width	manual operation
extension	250	300	350	400	450	500	550	600	650	70020	Standard	Bespoke arms	Standard	Bespoke arms
еженыюн	187-250	251-300	301-350	351-400	401-450	451-500	501-550	551-600	601-650	651-700				
150	28)										200	187	200	187
200	28)										250	237	250	237
250		28)									300	287	300	287
300			28)					17)	27) 17)		350	337	350	337
35017)				28)					20) 21) 55)		400	387	400	387
40017) 19) 25)					28)	24)	1)			1) 23) 54)	450	437	450	437

dimensions in cm

- with one Rolltex bearing.

- 17) a shadeplus is not available
 19) awnings with 4 m extension are only available with motor (surcharge).
 20) no intermediate sizes possible below the standard width of 650 cm.
- 21) awnings with 3 arms are only available with motor (surcharge).23) no intermediate sizes possible below the standard width of 700 cm.

- 23) no interinded sizes possible below the standard width of 700 to 24) rolltex bearing only from a width of 465 cm.
 25) an extension of 400 cm is supplied without interior cover profile.
 27) with shadeplus, 3 folding arms.
 28) Please note the minimum widths!
 54) smallest awning width with 3 arms 700 cm.

- 55) smallest awning width with 3 arms 641 cm.

Due to the compact awning construction and depending on the width and the arm length, contact between cover and folding arms may occur during extension and retraction. This does not affect the functionality or longevity of the awning.

	operation type	
	manual operation with st. steel winding handle	•
	Servo-assisted operation	0
	radio-controlled motor	0
	motor	0
	Shadeplus	
	manual operation	0
	radio-controlled motor	-
	motor	_
	Lighting	
	Halogen Spotlights	_
	Fluorescent lighting	-
	covers	
	acrylic 34 (fabric series 341xx-347xx)	•
	sunsilk SNC (fabric series 324xx/329xx)	•
	signature (fabric series 369xx)	•
ns	transilk FR (fabric series 319xx)	-
tio	transolair (fabric series 339xx)	_
Ор	widely woven acrylic (fabric series 349xx)	-
ion	perla FR (fabric series 374xx/379xx)	0
rat	Soltis 92	02
igu	PVC fabric	02
configuration options	miscellaneous	
ŭ	Coverboard	-
	Sytem coverboard	-
	wall sealing profile	○3
	Pitch adjustment gear	_
	Insertable side blind	0
	sun and wind sensor	0
	Valance	0
	Infrared heater	0
	Vibrabox / Sunis sun sensor	0
	Coupled units (please refer to fixture)	
	coupled unit 2 fields	0
	coupled unit 3 fields	0
	junction roller	0
	one-piece cover (on request)	0

Definition of extension: The extension is measured with the awning extended at a pitch of approx. 15 $^{\circ}$ from the wall over the cover to the leading edge of the front profile. The extension tolerance is - 40mm / + 40mm

= available, 2 folding arms

= available, 3 folding arms

In the case of manual operation, assume approx. 16 winding handle revolutions per metre of awning extension.

Extension when using a motor takes approximately 12 seconds per metre.

Definition of shadeplus drop: The shadeplus drop is measured from the bottom edge of the shadeplus profile to the bottom edge of the valance profile. Because of tolerances in fabric thicknesses the drop may be shorter by up to 5 cm. $\,$

- A shadeplus with gear is available in drops of 150 cm and 190 cm. A shadeplus is not possible with PVC covers.
- A shadeplus with motor is not possible.

coupled folding-arm awnings are available up to a max. of 3 single units side by side, however only with 6 folding-arms at most and only

Optionally available with junction roller. Pattern repeat mismatches are possible in the case of junction roller covers.

except when the extension is the maximum for the width of each awning. (see also arm separation table)

one-piece awning covers only on request.

If coupled awnings are to be fitted into ${\bf a}$ recess or reveal the overall width of the coupled blind or awning must be at least 6 cm less than the width of the opening to allow the blind/awning to be coupled. Make a special note if the awning is to be fitted into a recess/reveal and note the reveal width separately.

fran	ne colours	
	RAL 9016 traffic white	•
	RAL 8019 grey brown	•
	RAL 9006 metallic aluminium	•
	RAL 1015 light ivory	•
	5204 Nano anthracite metallic 5204 (Lounge)	0
	5215 Nano stone grey metallic 5215 (Lounge)	0
	5233 Nano off-white textured finish (Lounge)	0
	non-standard RAL colour	0

- = fitted as standard
 = optional accessory
- = not available
- °² = PVC/Soltis 92 covers available up to a max. width of 600 cm and a max. arm length of 250 cm.
- \circ ³ = wall sealing profile effective up to an awning pitch of 35°

fixings and accessories

	Face fixture bracket assembly	000000	Component assembly spreader plate A		Component assembly spreader plate B
77921.	150mm 5 - 35°	75328.	160x430x12mm	75327.	300x400x12mm
	Top fixture bracket assembly	0	Face fixture bracket assembly		stand-off strip for wall sealing profile
77937.	135mm 5 - 35°	77936.	150mm 38 - 65°	751971	available by the metre Fixture example, see face fixture with wall sealing profile
	Eaves fixture bracket assembly 5 - 35°		Top fixture bracket assembly		reducing bolt assembly M 16 - M 12 / SW 27 50mm length
77939.		77938.	150mm 38 - 65°	753891	(please refer to "Technical Information")
	Eaves fixture bracket assembly		Bottom fixture bracket assembly		reducing bolt assembly M 10 - M 10 / SW 27
77940.	270mm	77941.	5 - 35°	754901	50mm length (please refer to "Technical Information")
	Angle and fixture plate for eaves fixture	1080 09 O	Spacer plate face/ top fixture		Reduction assembly M 12 - M 10 / SW 27
741290	machine finish	716331	136x150x20mm N.B! stack to a max. of 200 mm	754911	50mm length (please refer to "Technical Information")
0	Additional eaves fixture plate		Spacer plate face/ top fixture		reducing bolt assembly M 16 - M 10 / SW 27
0.00	60x260x12mm		136x150x12mm		50mm length (please refer to "Technical Information")
75383.	analod profile	71644.	Cover plate for	754921	
	angled profile		Cover plate for external insulation		
	160x160x12mm		178x190x2mm		
	available by the metre, undrilled	0			
701809		71837.			

^{. =} Please insert the RAL No. (please refer to the section on "Coatings")


Face fixture

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

			CO	mpres	sion-p	roof s	ubstro	ate		ı	ı		non	comp	ressio	n-pro	of sub	strate		
					М [cm]									М [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]					FB	[N]		-							FB	[N]				
150	505	583	661	739	816	894	972	1050	1127	935	578	667	756	845	934	1023	1112	1201	1290	1070
200	834	957	1079	1202	1324	1447	1569	1692	1815	1603	955	1095	1235	1376	1516	1656	1796	1936	2077	1834
250		1364	1541	1717	1894	2071	2247	2424	2937	2622		1561	1763	1965	2167	2370	2572	2774	3361	3001
300		1	2079	2319	2559	2799	3447	3726	4004	3597		ł	2379	2654	2929	3204	3945	4264	4582	4117
350				3101	3415	4231	4596	4961	4653	4929		-		3549	3908	4842	5260	5678	5326	5642
400										6233		-			5578	6108	6638			7133
HT BHT		2 1	50 mm			3 1	50mm		4 1	50 mm		2 1	50 mm			3 1	50mm		4 1	50 mm
BM			3			1	2		1	6			8	_		1	2	•	1	6

The pull-out force refers to the vertical centre to centre measurement between the fixture points of 90 mm. If this measurement is reduced, the pull-out force increases by 2% in the case of compression-proof substrates and by 19% in the case of non-compression-proof substrates.

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BM = no. of fixing points
WA = wall sealing profile




Face fixture with spreader plate A

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

			со	mpres	sion-p	proof s	ubstr	ate			ı		non	compi	ressio	n-proc	of subs	strate		
					M [cm]									М [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]					FB	[N]									FB	[N]				
150	244	282	319	357	394	432	469	507	544	428	347	400	453	507	560	613	667	720	773	608
200							815	874	725	571	655	739	822	906	990	1074	1158	1241	1031	
250		656	741	825	910	910 995 1080 1165			1412	1195		932	1052	1173	1294	1414	1535	1655	2006	1699
300			998	1113	910 995 1080 1165 1229 1344 1655 1789			1922	1641			1418	1582	1746	1910	2352	2542	2732	2332	
350				1488	1638	2030	2205	2380	2100	2233				2114	2328	2884	3133	3382	2985	3174
400	-				2337	2559	2781			2827					3320	3636	3952			4017
HT BHT		2 15	0 mm			3 15	0 mm		4 15	0 mm		2 15	0 mm			3 15	0 mm		4 15	50 mm
BP	2 2						2			3		- 7	2			-	2		:	3
DP		-	-				1			1		-					1			I
BM		1	6			2	0		2	:8		1	6			2	0		2	:8

The pull-out force refers to the vertical centre to centre measurement between the fixture points of **76 mm**. In the case of spreader plates a washer conforming to DIN 9021 must be used.

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BP = no. of spreader plates
DP = no. of spacer plates
BM = no. of fixing points
WA = wall sealing profile
75197.: stand-off strip for wall sealing profile




Face fixture with spreader plate B

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

			со	mpres	sion-p	proof s	substr	ate		ı	ı		non c	ompre	ession	-proof	subst	rate		
					М [cm]									M [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]			-	-	FB	[N]		-							FB	[N]				
150	144	167	189	211	233	255	278	300	322	253	151	174	197	220	243	266	289	313	336	264
200						482	517	429	248	284	321	357	394	430	466	503	539	448		
250						689	835	707		405	457	509	562	614	667	719	871	738		
300			591	659	727	795	979	1059	1138	971			616	687	758	829	1021	1104	1186	1013
350				880	969	1201	1305	1408	1243	1322				918	1011	1253	1361	1469	1296	1378
400					1383	1514	1646			1673					1442	1579	1716			1744
HT BHT		2 15	0 mm			3 15	0 mm		4 15	0 mm		2 15	0 mm			3 15	50 mm		4 15	50 mm
ВР	2 2								3		7	2			- :	2			3	
DP		_	-				1			1		-	-				1			1
BM			8			1	2		1	6			8			1	2		1	6

The pull-out force refers to the vertical centre to centre measurement between the fixture points of 350 mm. In the case of spreader plates a washer conforming to DIN 9021 must be used

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BP = no. of spreader plates
DP = no. of spacer plates
BM = no. of fixing points
75197.: stand-off strip for wall sealing profile




Face fixture with shadeplus

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

			со	mpres	sion-p	proof s	ubstr	ate		1	ı		non	comp	ressio	n-proc	of subs	strate		
					М [cm]									М [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]					FB	[N]									FB	[N]				
150	818											1097	1257	1418	1578	1739	1899	2060	2220	1807
200	1251	1457	1663	1869	2074	2280	2486	2692	2898	2510	1432	1667	1903	2139	2374	2610	2845	3081	3316	2873
250		1989	2270	2551	2831	3112	3393	3674	4291	3777		2276	2598	2919	3240	3562	3883	4205	4911	4322
300			2954	3319	3684	4049	4822			4994			3380	3798	4216	4634	5519			5715
HT BHT		2	150 m	ım	•	3	150 n	nm	4 1 !	50 mm		2	150 n	nm		3	150 n	nm	4 1	0 mm
BM			8				12		1	6			8				12	·	1	6

The pull-out force refers to the vertical centre to centre measurement between the fixture points of 90 mm. If this measurement is reduced, the pull-out force increases by 2% in the case of compression-proof substrates and by 19% in the case of non-compression-proof substrates.

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BM = no. of fixing points
WA = wall sealing profile



Face fixture with shadeplus and spreader plate A


Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

			COI	mpres	sion-p	roof s	ubstro	ate		ĺ	Ī		non	compr	essior	n-proo	f subs	trate		
					M [cm]									М [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]					FB	[N]									FB	[N]				
150	394									738	560	656	752	848	944	1040	1136	1232	1328	1048
200	602							1294	1393	1161	855	996	1136	1277	1417	1558	1699	1839	1980	1650
250		955	1090	1225	1360	1494	1629	1764	2060	1749		1357	1549	1740	1932	2123	2315	2507	2928	2485
300			1417	1592	1767	1942	2313			2309			2014	2262	2511	2760	3288			3282
HT BHT		2 15	0 mm			3 15	50 mm		4 15	0 mm		2 15	50 mm			3 15	0 mm		4 15	0 mm
ВР			2			:	2		•	3			2			:	2		-	3
DP		-	-				1	·		ı		-	-				1			ı
BM		1	6			2	0		2	8		1	6			2	0		2	8

The pull-out force refers to the vertical centre to centre measurement between the fixture points of **76 mm**. In the case of spreader plates a washer conforming to DIN 9021 must be used.

M = overall awning width

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BP = no. of spreader plates
DP = no. of spacer plates
BM = no. of fixing points
WA = wall sealing profile
75197.: stand-off strip for wall sealing profile




Face fixture with shadeplus and spreader plate B

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

			со	mpres	ssion-p	proof s	ubstr	ate		ı	ı		non	comp	ressio	n-proc	of subs	strate		
					M [cm]									М [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]					FB	[N]									FB	[N]				
150	233								553	437	243	285	327	368	410	452	493	535	577	455
200	356	415	473	532	590				824	687	371	432	493	555	616	677	738	799	860	716
250		565	645	725	590 649 707 766 805 884 964 1044			1219	1035		589	673	756	839	922	1005	1089	1272	1079	
300			839	942	1046	1149	1369			1367			874	983	1091	1199	1428			1425
HT BHT		2 15	0 mm			3 15	0 mm		4 15	0 mm		2 15	0 mm			3 15	0 mm		4 15	0 mm
ВР	2 150 mm 2					;	2			3		;	2			:	2		1.	3
DP		-	-				1		1	1		-	-				1		1	1
BM			8			1	2		1	6			8			1	2		1	6

The pull-out force refers to the vertical centre to centre measurement between the fixture points of **350 mm**. In the case of spreader plates a washer conforming to DIN 9021 must be used.

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BP = no. of spreader plates
DP = no. of spacer plates
BM = no. of fixing points
75197.: stand-off strip for wall sealing profile



Top fixture

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2


com	nressia	on-proo	f sub	strate
COIII	טו כסטוי	טט וט־ווכ	ı sub	suute

non compression-proof substrate

					М [cm]									M [cm]				
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]					FB	[N]									FB	[N]				
150	463	537	611	685	759	833	908	982	1056	916	479	555	632	709	785	862	938	1015	1091	945
200	724	833	943	1052	1162	1271	1381	1491	1600	1445	750	864	977	1090	1204	1317	1431	1544	1658	1496
250		1156	1308	1461	1613	1766	1918	2070	2489	2252		1199	1357	1515	1673	1831	1989	2147	2582	2335
300	-		1734	1937	2140	2343	2869	3102	3335	3025			1800	2011	2221	2432	2978	3220	3462	3139
350				2557	2818	3477	3779	4081	3849	4081				2656	2926	3611	3925	4238	3997	4237
400					3974	4354	4733			5114					4129	4523	4917			5311
HT BHT		2 13	55 mm			3 13	35 mm		4 13	55 mm		2 13	55 mm			3 13	5 mm		4 13	55 mm
BM		(5				9		1	2		(5			9	9		1	2

The pull-out force refers to the horizontal centre to centre measurement between the fixture points of 125 $\,$ mm.

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BM = no. of fixing points




Top fixture with shadeplus

Pull-out force [N=Newton] per fixture point according to EN 13561, wind resistance class 2

	compression-proof substrate										non compression-proof substrate									
		M [cm]										M [cm]								
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]		FB [N]									FB [N]									
150	711	834	958	1081	1205	1329	1452	1576	1699	1426	736	865	993	1121	1249	1377	1505	1633	1761	1476
200	1054	1229	1405	1581	1756	1932	2107	2283	2459	2164	1093	1276	1458	1640	1822	2004	2186	2368	2550	2244
250		1651	1886	2121	2356	2591	2826	3061	3562	3167		1714	1958	2202	2446	2690	2933	3177	3698	3287
300			2428	2730	3031	3333	3958	1		4132		-	2521	2835	3148	3462	4111	-		4290
HT BHT		2 135 mm 3 135 mm 4						4 13	5 mm	2 135 mm 3 135 mm 4 1						4 13	35 mm			
RM			6		9 12				6				9				12			

The pull-out force refers to the horizontal centre to centre measurement between the fixture points of 125 mm.

M = overall awning width
H = extension
FB = pull-out force per fixing point
HT | BHT = bracket quantity | width
BM = no. of fixing points




Eaves/Roof timber fixture

Pull-out force [N=Newton] for the fixture bracket next to the arm according to EN 13561, wind resistance class 2

	Torque										shear force									
		M [cm]										M [cm]								
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]	Md [Nm]									FS [N]										
150	104	120	136	152	168	184	200	216	232	193	1282	1485	1688	1891	2094	2297	2499	2702	2905	2490
200	172	197	222	248	273	298	323	349	374	330	2035	2340	2646	2951	3257	3562	3867	4173	4478	4018
250		281	317	354	390	427	463	499	605	540		3272	3701	4131	4560	4989	5419	5848	7046	6351
300			428	478	527	577	710	767	825	741		ł	4933	5508	6082	6657	8165	8828	9490	8584
350				639	703	872	947	1022	959	1015		-	-	7299	8040	9934	10795	11655	10976	11633
400					1004	1099	1195			1284		-			11381	12466	13552			14617
HT	2 3						4	4	2 3							4				
BM		8	3			1	2		1	6	8 12						1	6		

The shear force are calculated from 2 fixture points per bracket, because depending on the roof pitch it cannot be guaranteed that 4 fixture points per bracket can used.

M = overall awning width
H = extension
Md = torque value for the bracket next to the arm
FS = shear force
HT = bracket
BM = no. of fixing points



Eaves fixture with additional plate


Pull-out force [N=Newton] for the fixture bracket next to the arm according to EN 13561, wind resistance class 2

	Torque										shear force									
	M [cm]										M [cm]									
	250	300	350	400	450	500	550	600	650	700	250	300	350	400	450	500	550	600	650	700
H [cm]	Md [Nm]									FS [N]										
150	104	120	136	152	168	184	200	216	232	193	646	751	856	961	1066	1171	1276	1381	1486	1313
200	172	197	222	248	273	298	323	349	374	330	984	1136	1287	1438	1589	1740	1892	2043	2194	2001
250		281	317	354	390	427	463	499	605	540		1555	1762	1969	2176	2383	2590	2797	3350	3050
300			428	478	527	577	710	767	825	741		-	2316	2588	2861	3133	3826	4137	4449	4055
350				639	703	872	947	1022	959	1015				3394	3742	4608	5009	5410	5118	5427
400					1004	1099	1195			1284					5245	5747	6250			6770
HT	2 3							4	2 3						4					
ВМ	4					6 8			3	4				6				8		


By using the additional flat plate, the shear force is reduced in comparison with conventional eaves fixture.

M = overall awning width


M = overall winning width
H = extension
Md = torque value for the bracket next to the arm
FS = shear force
HT = bracket
BM = no. of fixing points




bottom fixture



dimensions at pitches of 38° to 65°



Bracket range for awnings with 2 folding arms



M [cm]		SB	250	300	350	400	450	500	550	600	650				
IVI [CIII]	ZB		250 251-300		301-350	351-400	401-450	451-500	501-550	551-600	601-650				
			A [cm]												
	150		190 ■	230	270	300	340	380	440	490	510				
H [cm]	200		220 🔺	230 -	270	300	340	380	440	490	510				
		250		270 🔺	270 -	300	340	390	440	490	510				
		300			320 🔺	340 ■	340	390	440	490	510 △				
		350			-	370 ▲	390 ■	390	440	490					
	400						420 ▲	435 ▲	440 =						
W	ВНТ	150 mm		2	2		3								
DE/DA	HT	135 mm		2	2	·	3								

dimensions in cm

- ▲ = coupled units not available with junction roller
- = coupled units are only available with junction roller in the standard widths, in other widths on request

M = overall awning width


A = arm position
HT = bracket
MB = range for bracket fixture
LR = Rolltex bearing with bracket is always situated under the central seam (only at an extension of 400 cm)

H = extension

H = extension
SB = standard width
ZB = intermediate width
W = face fixture
DE/DA = top fixture and eaves fixture
HT | BHT = bracket quantity | width

If the brackets cannot be positioned in accordance with this table, make sure the actual measurements are noted on the order form!

Bracket range for awnings with 3 folding arms



M [cm]		SB		6.	50		700								
	ZB		601-	-650	650		651-674		675-700		651-692		693-700		
			A [cm]	B [cm]	A [cm]	B [cm]	A [cm]	B [cm]	A [cm]	B [cm]	A [cm]	B [cm]	A [cm]	B [cm]	
H [cm]		150					570	265	590	265					
		200					570	240	590	240					
		250					570	230	590	230					
		300	570 ▲	230 🛦			570	230	590	230					
		350			620 ▲	220 🛦					620 ▲	225 🛦	620	225	
		400										-	670 •	234 •	
W	BHT	150mm						4	1						
DE/DA	보	135mm						4	1						

dimensions in cm

- ▲ = coupled units not available with junction roller
- = no coupled units possible

M = overall awning width

M = overall awning width
A = arm position
B = arm position
HT = bracket
MB = range for bracket fixture
LR = Rolltex bearing with bracket is always situated under the central seam (depends on the width)
H = extension
SB = standard width
ZB = intermediate width
W = face fixture
DE/DA = top fixture and eaves fixture
HT | BHT = bracket quantity | width

If the brackets cannot be positioned in accordance with this table, make sure the actual measurements are noted on the order